



INSTRUCTIONS

1. Remove plastic backing from gel pads.
2. Position the gel pads on top of the bar and on the drops, anywhere your hands are when you ride.
3. Wrap your handlebar tape over the gel pads and feel the vibration-dampening comfort!