



For Models 7009, 7010, 7011, 7012, 7013



INSTALLATION INSTRUCTIONS FOR QUICK MOUNT SYSTEM

- 1** Thread **SCREW** into **CLIP**. Just start to tighten the screw, do not fully tighten it until setup is complete.
- 2** Snap the **STAY ATTACHMENT** into the **CLIP**.
- 3** Slide the **CLIPS** onto the fender (2 for front, 4 for rear).
- 4** Attach **STAYS** to bike (Refer to **Step 5** on **FREDDY FENDERS INSTALLATION INSTRUCTIONS** page). Slide the **SLEEVES** over the **STAYS**.
- 5** Slide **STAYS** into **STAY ATTACHMENT** (diagram #4) and firmly tighten **SLEEVE**.
- 6** Adjust fender to the correct position so it is not rubbing against the tire.
- 7** Tighten **SCREWS** on **CLIPS** to secure their position on the fender.

NOTE: You may need to shorten the stainless steel **STAYS** for a more precise fit.