



Shoe Cover Sizing Chart

Dasher (toe covers)

	S	M	L	XL	XXL
Euro	< 39	40 - 42	43 - 44	45 - 46	47 +
Mens	< 6	6.5 - 8.5	9 - 10	10.5 - 12	12.5 +
Womens	< 7.5	8 - 10	10.5 - 11	11.5 +	

Comet and Blitzen (shoe covers)

	S	M	L	XL	XXL	XXXL
Euro	< 40	40.5 - 41.5	42 - 43	44 - 45	46-47	47+
Mens	< 6.5	7 - 8	8 - 9	10 - 11	11.5 - 12.5	13+
Womens	< 8	8.5 - 9.5	10 - 11	11.5 +		

Fit Notes:

1. Size chart reflects approx size needed for standard mtn./road shoes.
2. For cycling shoes with a street shoe design, add 1.5 to your european shoe size.
3. For winter cycling shoes add 2 to your european shoe size.
4. The outer size of shoes will vary depending on brand and style. For best fit try them on at your local bike shop.