



Corky Grips - Installation Instructions

1. Cut or twist off your old grips.
2. Clean your handlebars (isopropyl alcohol is best) and allow to dry.
3. Securing grips to handlebar:
It is critical that you secure the grips to your handlebar using either glue or a layer of cloth tape.

Glue- Using a multi-purpose household glue that is approved for wood and metal, apply glue to the outer 3-4 inches of the handle bar (all the way around the bar diameter). Then slide the grip on to the bar while rotating slightly. Allow glue to dry as recommended. Once fully dry, test thoroughly before riding to ensure grip can not slip or twist.

Cloth tape- Wrap the handle bar with a thin layer of cloth handlebar tape, covering 2-3 inches of the bar where the middle of the grip will sit. Gently slide the grip over the tape, rotating in the same direction as the tape. Test thoroughly before riding to ensure grip can not slip or twist.

4. Sealing grips:
Although it is not necessary to seal your new cork grips it will prolong the life, keep them cleaner and give them a great look. We recommend using a clear or tinted shellac.
5. Nice job, now go out and ride!